

# Assembly Instructions

## Parts



- 1 x Ball float
- 1 x Rod
- 1 x Float stopper
- 1 x 'C' clip
- 1 x Self tapping screw

## Completed Product



## Instructions

1. Insert float stopper to bottom of rod (*non-threaded end*).
2. Tighten self-taping screw through hole in stopper onto rod.



3. Slide ball float on to rod (*note orientation of ball float*).
4. Insert C clip.



4. Insert C clip.



# Installation Instructions

1. Remove 2 screws on bracket holding float switch.



2. Remove 4 screws in Float switch.



3. Carefully remove whole unit.



4. Unscrew Top – Ensure to keep all parts.



5. Disassemble and reuse parts.



6. Replace with new fixed float arm and reinstall - be sure to insert arm back to correct orientation.



## Completed Products



B18-FF, B25-FF & B45-FF



B75-FF



AUTOSUB