


MH40T-2 Parts Breakdown



MH40T-2 Parts Breakdown

No	Code	Part No	Description	Qty
1	402109	100SP-01	Filter net	1
2	402150	100ZB-019	Clamp	3
3	402131	100ZB-001	Nut – Hose Barb	2
4	402132	100ZB-002	Hose Barb	2
5	402133	100ZB-003	Rubber Gasket for Hose Barb	2
6	402111	100SP-02	Bolt M12*35	10
7	402112	100SP-03	Spring washer 12	14
8	402113	100SP-04	Suction Flange	1
9	416388	HP200-007	Plug 1"	2
10	416389	HP200-008	O-Ring for Plug	2
11	402114	100SP-05	Rubber Gasket – Suction Flange / NRV	1
12	414623	80SP-007	Quincunx nut (for Pump Case)	4
13	402115	100SP-06	Washer 14	4
14	402116	100SP-07	Pump Case - Front	1
15	402117	100SP-08	O-Ring – Pump Case	1
16	402118	100SP-09	Rubber packing ring	1
17	402119	100SP-10	Diffuser	1
18	402120	100SP-11	Impeller	1
19	414629	80SP-014	Bolt M8*35	3
20	-		Spacers	3
21	402121	100SP-12	Bolt M8*50	4
22	408461	50ZB-017	Washer 8	4
23	402122	100SP-13	Bolt M12*50	2
24	414633	80SP-018	Mechanical Seal	1
25	414638	80SP-023	Eyelet bolt (Pump Case)	4
26	402123	100SP-14	Rubber gasket – Discharge Case	1
27	414636	80SP-021	Bolt M12*45	2
28	402124	100SP-15	Pump Case - Rear	1
29	414622	80SP-006	Spring washer 10	4
30	414653	80ZB-004	Bolt M10*30	4
31	402125	100SP-16	Discharge Case 4"	1
32	414641	80SP-026	O-Ring for Plug 1-1/4"	1
33	414642	80SP-027	Plug 1-1/4"	1
34	402126	100SP-17	Rubber Gasket – Discharge Flange	1
35	402127	100SP-18	Discharge Flange	1
36	414666	80ZB-017	Nut M8	1
37	414646	80SP-031	Spring washer 8	1
38	-	100SP-19	Washer for NRV Front	1
39	-	100SP-20	Rubber NRV Flap	1
40	-	100SP-21	Washer for NRV Front	1
41	-	100SP-22	Washer 8	1
42	-	100SP-23	Bolt M8*20	1